

# PHILIPS VIDEOPAC 30



Battlefield  
Schlachtfeld  
Champ de bataille  
Slagveld  
I due generali  
Guerillakrig  
Fånga Generalen  
Campo de batalla  
A batalha

**PHILIPS**



# Instructions for Use

## Battlefield

### First read these instructions before you start to play

(2 players) Press RESET  
Next press key 1

Your screen shows a small forest and two armies, each with a general. In the left-hand top corner you'll see the blue general and his four soldiers (left handset), in the right-hand bottom corner a yellow general with his four soldiers (right handset).

The purpose of the game is to capture the enemy general. If you succeed in capturing him ten times, you have won the war.

### How the game is played

You cannot control your soldiers directly. They will automatically try and find their way to the other general. When they encounter enemy soldiers, they may shoot them... or get shot by an enemy bullet. When hit by a bullet, they are stunned and will not move any more. The generals are invulnerable to enemy bullets.

You can move your general however with the joystick of your handset. This way you may try and escape from pursuing enemy soldiers. Your general can also re-animate your soldiers that have been shot. When he touches them, they will revive.

As a true general he may also lead his men to the enemy camp. Use the joystick to control his movements. When you press the action button, he will beckon his soldiers to follow him. They will, provided their way isn't blocked by trees or soldiers. Once they have a clear path to the opposing general, you can let them go and they will pursue him automatically.

When one of the generals is captured, both officers first act in a very gentlemanly fashion but not for long. There's not much time to

rejoice because the game continues immediately and winning a battle doesn't mean you have won the war! It takes ten victories to win one war with this Videopac game.

### Starting a new series

Immediately after one war has been fought and the winner is known, a next one will start so you continue to play.

### Check procedure

If you suspect a fault in the equipment follow this procedure (with a Videopac installed). Press RESET ( $\Delta$ ). The TV will emit a short sound, and 'SELECT GAME' should appear on your TV screen. If not, ensure that the equipment is set up properly as detailed in the Instructions for Use (both of the


equipment, and of the Videopac used). If the fault remains, take both the equipment and Videopac to your dealer.

Score blue army  
(left handset)

Trees

No score for blue army


Blue general  
Blue soldiers



**Start of the game**

Both generals and their four-man armies are still in their own corners. Soldiers will automatically start searching for the opposing general.

Yellow soldiers  
Score yellow army (right handset)



Yellow soldier has captured the blue general  
Yellow general salutes his opponent

Yellow army has scored one point

**Game situation**


Yellow army scores its first victory



Press action button and general beckons his soldiers to follow him

Use joystick to move your general

Blue army has scored one point  
Blue general jumps with joy  
Blue soldier has captured yellow general




**Game situation**

Blue army scores its first victory

Soldiers stunned by enemy bullet. They will come to life again when touched by their general

Score blue army

Blue general, the victor, grows in stature when he celebrates his victory



**Game situation**

War is over. The blue army has scored ten victories

Score yellow army

Each time a game is finished, press RESET (.), 'SELECT GAME' is shown on the screen. Now:

- (a) Select another game.
- Or (b) Select another Videopac. Remove existing Videopac by placing one hand next to it, and pulling handle upwards. Replace Videopac in its box.

Refer now to instructions for Use of the next Videopac.  
Or (c) Plug aerial back into TV, and unplug the Videopac Computer from the mains.

A copyright protection is claimed  
on the program stored within the cartridge.

© 1981 N.V. Philips' Gloeilampenfabrieken

3111 106 62790

SIP